

# U RESIN BALM

## HOW TO:

When applying the balm ensure the board is clean of any sanding dust etc or else it will get trapped.

When applying the balm be sure to get some heat/friction going, this will help with viscosity and the wax and oil will penetrate better.

Use the balm heavily, different woods and grains will absorb the balm differently, in most cases a few coats will need to be applied leaving a few hours between to allow the balm to absorb and cure.

After the final coat wipe excess balm off after a few hours and wait 12-24 hours to fully cure before use.

Repeat this process every 2-3 months or earlier depending on use to keep the board looking good and stay protected.

